

メーカー	サイズ(型)	型式	ネジ穴寸法		ネジ穴寸法							
			W	H	CR-LAST6	CR-LAST7	100-TV004	CR-PL13	CR-PL17	CR-PLKG2	CR-PLKG5	
日立	37	L37-XP03	200	200	○	○	○	○	×	○	○	
		L37-XP035	200	200	○	○	○	○	×	○	○	
		L37-XP05	200	200	○	○	○	○	×	○	○	
		L37-XP07	200	200	○	○	○	○	×	○	○	
		L37-XP700CS	200	200	○	○	○	○	×	○	○	
		L37-XP08	200	200	○	○	○	○	×	○	○	
		L37-XP800CS	200	200	○	○	○	○	×	○	○	
		L37-ZP05	200	200	○	○	○	○	×	○	○	
		UT37-BX700J	400	200	×	×	×	×	×	×	×	
		UT37-XP770B/W	400	200	×	×	×	×	×	×	×	
	UT37-XP800B/W	400	200	×	×	×	×	×	×	×		
	UT37-XV700	400	200	×	×	×	×	×	×	×		
	32	L32-H05				×	×	×	○	×	○	○
		L32-WP03	200	200	○	○	○	○	×	○	○	
		L32-XP05	200	200	○	○	○	○	×	○	○	
		L32-XP07	200	200	○	○	○	○	×	○	○	
		L32-XP700CS	200	200	○	○	○	○	×	○	○	
		L32-XP08	200	200	○	○	○	○	×	○	○	
		L32-XP800CS	200	200	○	○	○	○	×	○	○	
		UT32-BX700JB/W/R/A	400	200	×	×	×	×	×	×	×	
UT32-HV700/B/R/A		400	200	×	×	×	×	×	×	×		
UT32-XP770B・W		400	200	×	×	×	×	×	×	×		
UT32-XP800B/W	400	200	×	×	×	×	×	×	×			

の機種は壁掛け対応にする為に純正アタッチメントが必要

※・・・背面部の端子が隠れる部分があります。

・・・付属のワッシャーでの取付け不可。別途ワッシャー(外径20~30mm)が必要