


## HW Grabber USB Firmware Upgrade SOP

### HW Grabber FW Upgrade

1. Pls move the firmware file to USB storage



2. Plug in the power cable



3. Plug in USB storage



## HW Grabber USB Firmware Upgrade SOP

---

4. Turn on the power switch and see the green light at the same time, pls wait.



5. The green light will change to red(upgrading)



6. Upgrade finish, the LED will be restored to green light



7. Pls reboot the HD grabber.