



■Acer

シリーズ名	ノートパソコン		対応 コネクタ
	モデル名	型番	
Aspire one	A0531h	A0531h-MCK11	E
Aspire one	A0531h	A0531h-MCB11	E
Aspire one	A0751	A0751-Bk23	E
Aspire one	A0751	A0751-Bk23F	E
Aspire one	A0751	A0751-Bk26	E
Aspire one	A0751	A0751-Bk26F	E
Aspire one	A0751	A0751-Bw23	E
Aspire one	A0751	A0751-Bw23F	E
Aspire one	A0751	A0751-Bw26	E
Aspire one	A0751	A0751-Bw26F	E
Aspire one	A0751	ZEI-A0751BK23	E
Aspire one	A0751	ZEI-A0751BK23F	E
Aspire one	A0751	ZEI-A0751BK26	E
Aspire one	A0751	ZEI-A0751BK26F	E
Aspire one	A0751	ZEI-A0751BW23	E
Aspire one	A0751	ZEI-A0751BW23F	E
Aspire one	A0751	ZEI-A0751BW26	E
Aspire one	A0751	ZEI-A0751BW26F	E
Aspire one	A0752	A0752-H22C/K	E
Aspire one	A0752	A0752-H22C/W	E
Aspire one	AOA150	AOA150-Bb	E
Aspire one	AOA150	AOA150-Bw	E
Aspire one	AOA150	ZEI-AOA150BB	E
Aspire one	AOA150	ZEI-AOA150BB	E
Aspire one	AOA150	ZEI-AOA150BW	E
Aspire one	AOA150	AOA150-Bb1	E
Aspire one	AOA150	AOA150-Bk1	E
Aspire one	AOA150	AOA150-Bw1	E
Aspire one	AOA150	ZEI-AOA150BB1	E
Aspire one	AOA150	ZEI-AOA150BK1	E
Aspire one	AOA150	ZEI-AOA150BW1	E
Aspire one	AOA150	AOA150-Bbdom	E
Aspire one	AOA150	AOA150-Bcdom	E
Aspire one	AOA150	AOA150-Bkdom	E
Aspire one	AOA150	AOA150-Bpdom	E
Aspire one	AOA150	AOA150-Bwdom	E
Aspire one	AOA150	AOA150-Bc1	E
Aspire one	AOA150	AOA150-Bp1	E
Aspire one	AOD250	AOD250-Bp83	E
Aspire one	AOD250	ZEI-AOD250BP83	E
Aspire one	AOD250	AOD250-Bw83	E
Aspire one	AOD250	AOD250-Bb83	E
Aspire one	AOD250	AOD250-Bk83	E
Aspire one	AOD250	AOD250-Br83	E
Aspire one	AOD250	AOD250-Bw83F	E
Aspire one	AOD250	AOD250-Bb83F	E
Aspire one	AOD250	AOD250-Bk83F	E
Aspire one	AOD250	AOD250-Br83F	E
Aspire one	AOD250	ZEI-AOD250BB83	E
Aspire one	AOD250	ZEI-AOD250BB83F	E
Aspire one	AOD250	ZEI-AOD250BK83	E
Aspire one	AOD250	ZEI-AOD250BK83F	E
Aspire one	AOD250	ZEI-AOD250BR83	E
Aspire one	AOD250	ZEI-AOD250BR83F	E
Aspire one	AOD250	ZEI-AOD250BW83	E
Aspire one	AOD250	ZEI-AOD250BW83F	E
Aspire one	AOD250	AOD250-Bb18	E
Aspire one	AOD250	AOD250-Bk18	E
Aspire one	AOD250	AOD250-Br18	E
Aspire one	AOD250	AOD250-Bw18	E
Aspire one	AOD250	ZEI-AOD250BB18	E
Aspire one	AOD250	ZEI-AOD250BK18	E
Aspire one	AOD250	ZEI-AOD250BR18	E
Aspire one	AOD250	ZEI-AOD250BW18	E
Aspire one	AOP531h	ZEI-AOP531HHD11	E

シリーズ名	ノートパソコン		対応 コネクタ
	モデル名	型番	
Aspire one	AOP531h	ZEI-AOP531HHD11DOM	E
Aspire one	AOP531h	ZEI-AOP531HSS11DOM	E
Aspire one	AOP531h	ZEI-AOP531HSS11	E
Aspire one	AOP531h	AOP531h-SS11	E
Aspire one	AOP531h	AOP531h-SS11DOM	E
Aspire one	AOP531h	AOP531h-HD11	E
Aspire one	AOP531h	AOP531h-HD11DOM	E
Aspire one	D150	AOD150-Bb73	E
Aspire one	D150	AOD150-Bbdom	E
Aspire one	D150	AOD150-Bk73	E
Aspire one	D150	AOD150-Bkdom	E
Aspire one	D150	AOD150-Br73	E
Aspire one	D150	AOD150-Brdom	E
Aspire one	D150	AOD150-Bw73	E
Aspire one	D150	AOD150-Bwdom	E
Aspire one	D150	ZEI-AOD150BB73	E
Aspire one	D150	ZEI-AOD150BBDOM	E
Aspire one	D150	ZEI-AOD150BK73	E
Aspire one	D150	ZEI-AOD150BKDOM	E
Aspire one	D150	ZEI-AOD150BR73	E
Aspire one	D150	ZEI-AOD150BRDOM	E
Aspire one	D150	ZEI-AOD150BW73	E
Aspire one	D150	ZEI-AOD150BWDOM	E

■NEC

ノートパソコン			対応 コネクタ
シリーズ名	モデル名	型番	
VersaPro	VJ13M/BB-B	PC-VJ13MBBCB	C
VersaPro	VJ13M/BB-B	PC-VJ13MBBHB	C
VersaPro	VJ13M/BB-B	PC-VJ13MBBCZCLB	C
VersaPro	VJ13M/BB-W	PC-VJ13MBBCW	C
LaVie Light	BL350/CW6B	PC-BL350CW6B	C
LaVie Light	BL350/CW6R	PC-BL350CW6R	C
LaVie Light	BL350/CW6W	PC-BL350CW6W	C
LaVie Light	BL350/DW6B	PC-BL350DW6B	C
LaVie Light	BL350/DW6R	PC-BL350DW6R	C
LaVie Light	BL350/DW6W	PC-BL350DW6W	C
LaVie Light	BL350/EW6B	PC-BL350EW6B	C
LaVie Light	BL350/EW6R	PC-BL350EW6R	C
LaVie Light	BL350/EW6W	PC-BL350EW6W	C
LaVie Light	BL350/FS6B	PC-BL350FS6B	C
LaVie Light	BL350/FS6R	PC-BL350FS6R	C
LaVie Light	BL350/FS6W	PC-BL350FS6W	C
LaVie Light	BL350/FW6B	PC-BL350FW6B	C
LaVie Light	BL350/FW6R	PC-BL350FW6R	C
LaVie Light	BL350/FW6W	PC-BL350FW6W	C
LaVie Light	BL550/CS6B	PC-BL550CS6B	C
LaVie Light	BL550/CS6R	PC-BL550CS6R	C
LaVie Light	BL550/CS6W	PC-BL550CS6W	C
LaVie Light	BL550/DS6B	PC-BL550DS6B	C
LaVie Light	BL550/DS6R	PC-BL550DS6R	C
LaVie Light	BL550/DS6W	PC-BL550DS6W	C
LaVie G	GL132A/6N	PC-GL132A6AN	C
LaVie G	GL132A/6N	PC-GL132A6GN	C
LaVie G	GL132A/6R	PC-GL132A6AR	C
LaVie G	GL132A/6R	PC-GL132A6GR	C
LaVie G	GL132B/6N	PC-GL132B6AN	C
LaVie G	GL132B/6N	PC-GL132B6GN	C
LaVie G	GL132B/6R	PC-GL132B6AR	C
LaVie G	GL132B/6R	PC-GL132B6GR	C
LaVie G	GL132C/6N	PC-GL132C6AN	C
LaVie G	GL132C/6N	PC-GL132C6GN	C
LaVie G	GL132C/6R	PC-GL132C6AR	C
LaVie G	GL132C/6R	PC-GL132C6GR	C
LaVie G	GL136A/6N	PC-GL136A6AN	C
LaVie G	GL136A/6N	PC-GL136A6GN	C
LaVie G	GL136A/6R	PC-GL136A6AR	C
LaVie G	GL136A/6R	PC-GL136A6GR	C
LaVie G	GL136B/6N	PC-GL136B6AN	C
LaVie G	GL136B/6N	PC-GL136B6GN	C
LaVie G	GL136B/6R	PC-GL136B6AR	C
LaVie G	GL136B/6R	PC-GL136B6GR	C
LaVie G	GL136C/6N	PC-GL136C6AN	C
LaVie G	GL136C/6N	PC-GL136C6GN	C
LaVie G	GL136C/6R	PC-GL136C6AR	C
LaVie G	GL136C/6R	PC-GL136C6GR	C
LaVie M	LM550/DS6B	PC-LM550DS6B	C
LaVie M	LM550/DS6R	PC-LM550DS6R	C
LaVie M	LM550/DS6W	PC-LM550DS6W	C
LaVie M	LM550/ES3EB	PC-LM550ES3EB	C
LaVie M	LM550/ES3ER	PC-LM550ES3ER	C

ノートパソコン			対応 コネクタ
シリーズ名	モデル名	型番	
LaVie M	LM550/ES3EW	PC-LM550ES3EW	C
LaVie M	LM550/ES6B	PC-LM550ES6B	C
LaVie M	LM550/ES6R	PC-LM550ES6R	C
LaVie M	LM550/ES6W	PC-LM550ES6W	C
LaVie M	LM570/DS	PC-LM570DS	C
LaVie M	LM570/ES	PC-LM570ES	C
LaVie M	LM750/DS6B	PC-LM750DS6B	C
LaVie M	LM750/DS6R	PC-LM750DS6R	C
LaVie M	LM750/DS6W	PC-LM750DS6W	C
LaVie M	LM750/ES6B	PC-LM750ES6B	C
LaVie M	LM750/ES6R	PC-LM750ES6R	C
LaVie M	LM750/ES6W	PC-LM750ES6W	C
LaVie M	LM758/DV01B	PC-LM758DV01B	C
LaVie M	LM758/DV01R	PC-LM758DV01R	C
LaVie M	LM758/DV01W	PC-LM758DV01W	C
LaVie Touch	LT550/FS	PC-LT550FS	C
VersaPro	VJ10E/BB-B	PC-VJ10EBBCB	C
VersaPro	VJ10E/BB-B	PC-VJ10EBBHB	C
VersaPro	VJ13L/BB-B	PC-VJ13LBBCB	C
VersaPro	VJ13L/BB-B	PC-VJ13LBBHB	C
VersaPro	VJ15E/ZS-G	PC-VJ15EZSEG	C
VersaPro	VJ15E/ZS-G	PC-VJ15EZSNG	C
VersaPro	VK10E/BB-B	PC-VK10EBBCB	C
VersaPro	VK10E/BB-B	PC-VK10EBBHB	C
VersaPro	VK13L/BB-B	PC-VK13LBBCB	C
VersaPro	VK13L/BB-B	PC-VK13LBBHB	C
VersaPro	VK13L/BB-B	PC-VK13LBBCHALB	C
VersaPro	VK13M/BB-B	PC-VK13MBBCB	C
VersaPro	VK13M/BB-B	PC-VK13MBBHB	C
VersaPro	VK13M/BB-B	PC-VK13MBBTHCMB	C
VersaPro	VK13M/BB-B	PC-VK13MBBCHCSB	C
VersaPro	VK13M/BB-B	PC-VK13MBBTHCSB	C
VersaPro	VK13M/BB-W	PC-VK13MBBCW	C
VersaPro	VK15E/ZS-G	PC-VK15EZSEG	C
VersaPro	VK15E/ZS-G	PC-VK15EZSNG	C

■富士通

ノートパソコン			対応 コネクタ
シリーズ名	モデル名	型番	
LIFEBOOK	FMV-645MC6C/W	FMV6MCGTL2	A
LIFEBOOK	FMV-645MC6C/W	FMV6MCGTL5	A
LIFEBOOK	FMV-645MC6C/W	FMV6MCGTL6	A
LIFEBOOK	FMV-645MC6C/W	FMV6MCGTM2	A
LIFEBOOK	FMV-645MC6C/W	FMV6MCGTM5	A
LIFEBOOK	FMV-645MC6C/W	FMV6MCGTM6	A
LIFEBOOK	FMV-645MC6C/W	FMV6MCGWL2	A
LIFEBOOK	FMV-645MC6C/W	FMV6MCGWL5	A
LIFEBOOK	FMV-645MC6C/W	FMV6MCGWL6	A
LIFEBOOK	FMV-645MC6C/W	FMV6MCGWM2	A
LIFEBOOK	FMV-645MC6C/W	FMV6MCGWM5	A
LIFEBOOK	FMV-645MC6C/W	FMV6MCGWM6	A
LIFEBOOK	FMV-645MC7C/W	FMV7MCGTL2	A
LIFEBOOK	FMV-645MC7C/W	FMV7MCGTL5	A
LIFEBOOK	FMV-645MC7C/W	FMV7MCGTL6	A
LIFEBOOK	FMV-645MC7C/W	FMV7MCGTM2	A
LIFEBOOK	FMV-645MC7C/W	FMV7MCGTM5	A
LIFEBOOK	FMV-645MC7C/W	FMV7MCGTM6	A
LIFEBOOK	FMV-645MC7C/W	FMV7MCGWL2	A
LIFEBOOK	FMV-645MC7C/W	FMV7MCGWL5	A
LIFEBOOK	FMV-645MC7C/W	FMV7MCGWL6	A
LIFEBOOK	FMV-645MC7C/W	FMV7MCGWM2	A
LIFEBOOK	FMV-645MC7C/W	FMV7MCGWM5	A
LIFEBOOK	FMV-645MC7C/W	FMV7MCGWM6	A
LIFEBOOK	FMV-650MC8/W	FMV8MCHTL2	A
LIFEBOOK	FMV-650MC8/W	FMV8MCHTL5	A
LIFEBOOK	FMV-650MC8/W	FMV8MCHTL6	A
LIFEBOOK	FMV-650MC8/W	FMV8MCHTL7	A
LIFEBOOK	FMV-650MC8/W	FMV8MCHTM2	A
LIFEBOOK	FMV-650MC8/W	FMV8MCHTM5	A
LIFEBOOK	FMV-650MC8/W	FMV8MCHTM6	A
LIFEBOOK	FMV-650MC8/W	FMV8MCHTM7	A
LIFEBOOK	FMV-650MC8/W	FMV8MCHWL2	A
LIFEBOOK	FMV-650MC8/W	FMV8MCHWL5	A
LIFEBOOK	FMV-650MC8/W	FMV8MCHWL6	A
LIFEBOOK	FMV-650MC8/W	FMV8MCHWL7	A
LIFEBOOK	FMV-650MC8/W	FMV8MCHWM2	A
LIFEBOOK	FMV-650MC8/W	FMV8MCHWM5	A
LIFEBOOK	FMV-650MC8/W	FMV8MCHWM6	A
LIFEBOOK	FMV-650MC8/W	FMV8MCHWM7	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKTL2	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKTL3	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKTL6	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKTL7	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKTLZ	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKTM2	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKTM3	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKTM6	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKTM7	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKTMZ	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKWL2	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKWL3	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKWL6	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKWL7	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKWLZ	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKWM2	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKWM3	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKWM6	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKWM7	A
LIFEBOOK	FMV-660MC9/W	FMV9MCKWMZ	A
LIFEBOOK	FMV-665MC2	FMV2MCLL2	A
LIFEBOOK	FMV-665MC2	FMV2MCLL3	A

ノートパソコン			対応 コネクタ
シリーズ名	モデル名	型番	
LIFEBOOK	FMV-665MC2	FMV2MCLL6	A
LIFEBOOK	FMV-665MC2	FMV2MCLL7	A
LIFEBOOK	FMV-665MC2	FMV2MCLM2	A
LIFEBOOK	FMV-665MC2	FMV2MCLM3	A
LIFEBOOK	FMV-665MC2	FMV2MCLM6	A
LIFEBOOK	FMV-665MC2	FMV2MCLM7	A
LIFEBOOK	FMV-665MC2	FMV2MCLTL2	A
LIFEBOOK	FMV-665MC2	FMV2MCLTL3	A
LIFEBOOK	FMV-665MC2	FMV2MCLTL7	A
LIFEBOOK	FMV-665MC2	FMV2MCLTM2	A
LIFEBOOK	FMV-665MC2	FMV2MCLTM3	A
LIFEBOOK	FMV-665MC2	FMV2MCLTM6	A
LIFEBOOK	FMV-665MC2	FMV2MCLTM7	A
LIFEBOOK	FMV-665MC2	FMV2MCLTW2	A
LIFEBOOK	FMV-665MC2	FMV2MCLTW3	A
LIFEBOOK	FMV-665MC2	FMV2MCLW2	A
LIFEBOOK	FMV-665MC2	FMV2MCLW3	A
LIFEBOOK	FMV-665MC2	FMV2MCLTL6	A
LIFEBOOK	FMV-670MC3	FMV3MCMTL2	A
LIFEBOOK	FMV-670MC3	FMV3MCMTL3	A
LIFEBOOK	FMV-670MC3	FMV3MCMTL7	A
LIFEBOOK	FMV-670MC3	FMV3MCMTM2	A
LIFEBOOK	FMV-670MC3	FMV3MCMTM3	A
LIFEBOOK	FMV-670MC3	FMV3MCMTM7	A
LIFEBOOK	FMV-670MC3	FMV3MCMTW2	A
LIFEBOOK	FMV-670MC3	FMV3MCMTW3	A
LIFEBOOK	FMV-670MC3	FMV3MCM2L2	A
LIFEBOOK	FMV-670MC3	FMV3MCM2L3	A
LIFEBOOK	FMV-670MC3	FMV3MCM2L7	A
LIFEBOOK	FMV-670MC3	FMV3MCM2M2	A
LIFEBOOK	FMV-670MC3	FMV3MCM2M3	A
LIFEBOOK	FMV-670MC3	FMV3MCM2M7	A
LIFEBOOK	FMV-670MC3	FMV3MCM2W2	A
LIFEBOOK	FMV-670MC3	FMV3MCM2W3	A
LIFEBOOK	FMV-680MC4	FMV4MC2SL2	A
LIFEBOOK	FMV-680MC4	FMV4MC2SL3	A
LIFEBOOK	FMV-680MC4	FMV4MC2SL7	A
LIFEBOOK	FMV-680MC4	FMV4MC2SM2	A
LIFEBOOK	FMV-680MC4	FMV4MC2SM3	A
LIFEBOOK	FMV-680MC4	FMV4MC2SM7	A
LIFEBOOK	FMV-680MC4	FMV4MC2STL2	A
LIFEBOOK	FMV-680MC4	FMV4MC2STL3	A
LIFEBOOK	FMV-680MC4	FMV4MC2STL7	A
LIFEBOOK	FMV-680MC4	FMV4MC2STM2	A
LIFEBOOK	FMV-680MC4	FMV4MC2STM3	A
LIFEBOOK	FMV-680MC4	FMV4MC2STM7	A
LIFEBOOK	FMV-680MC4	FMV4MC2STW2	A
LIFEBOOK	FMV-680MC4	FMV4MC2STW3	A
LIFEBOOK	FMV-680MC4	FMV4MC2SW2	A
LIFEBOOK	FMV-680MC4	FMV4MC2SW3	A
LIFEBOOK	FMV-B8210	FMVNB2F3	A
LIFEBOOK	FMV-B8210	FMVNB2F8	A
LIFEBOOK	FMV-B8210	FMVNB2FT3	A
LIFEBOOK	FMV-B8210	FMVNB2FT8	A
LIFEBOOK	FMV-B8210	FMVNB2H3	A
LIFEBOOK	FMV-B8210	FMVNB2H8	A
LIFEBOOK	FMV-B8220	FMVNB3W3	A
LIFEBOOK	FMV-B8220	FMVNB3W8	A
LIFEBOOK	FMV-B8220	FMVNB3Y3	A
LIFEBOOK	FMV-B8220	FMVNB3Y8	A
LIFEBOOK	FMV-B8220	FMVNB3YT3	A
LIFEBOOK	FMV-B8220	FMVNB3YT8	A

ノートパソコン			対応 コネクタ
シリーズ名	モデル名	型番	
LIFEBOOK	FMV-B8220	FMVNB3YTT	A
LIFEBOOK	FMV-B8230	FMVNB4W3	A
LIFEBOOK	FMV-B8230	FMVNB4W8	A
LIFEBOOK	FMV-B8230	FMVNB4Y3	A
LIFEBOOK	FMV-B8230	FMVNB4Y8	A
LIFEBOOK	FMV-B8230	FMVNB4YT3	A
LIFEBOOK	FMV-B8230	FMVNB4YT8	A
LIFEBOOK	FMV-B8230	FMVNB4YTT	A
LOOX	LOOX T5全モデル		A
BIBLO	MC2/40	FMVMC240	A
BIBLO	MC2/40	FMVMC240S	A
BIBLO	MC3/45	FMVMC345	A
BIBLO	MC3/45	FMVMC345S	A
BIBLO	MC4/45C	FMVMC445C3	A
BIBLO	MC4/45C	FMVMC445CS	A
BIBLO	MF3/500X	FMVMF350X	A
BIBLO	MF4/45D	FMVMF445D3	A
BIBLO	MF4/600R	FMVMF460R	A
BIBLO	MG9/85C	FMVMG985C	A
LOOX	P70R		A
LOOX	P70S		A
LOOX	P70T		A
LOOX	P70TN		A
LOOX	P70U/V	ZFJ-FMVLP70UV	A
LOOX	P70U/V	FMVLP70UV	A
LIFEBOOK	P8210		A
LIFEBOOK	P8230		A
LOOX	T5/53		A
LOOX	T5/53W		A
LOOX	T8/80		A
LOOX	T8/80W		A
LOOX	T7/63		A
LOOX	T7/63W		A
LOOX	T86A	FMVLT86A	A
LOOX	T86AW	FMVLT86AW	A
LOOX	T86A		A
LOOX	T86AW		A
LOOX	T9/80M	FMVLT980M	A
LOOX	T9/80W	FMVLT980W	A
LOOX	T9/80M		A
LOOX	T9/80W		A
LOOX	T93B	FMVLT93B	A
LOOX	T93B/W	FMVLT93BW	A
LOOX	T93C	FMVLT93C	A
LOOX	T93C/W	FMVLT93CW	A
LOOX	T93B		A
LOOX	T93C		A
LOOX	P/A70N	FMVLP A70N	A
LOOX	P/A70N	FMVLP A70NV	A
LOOX	P/B70N	FMVLP B70N	A
LOOX	P/B70N	FMVLP B70NV	A
LOOX	P50WN	FMVLP50WN	A
LOOX	P50WN	FMVLP50WNV	A
LOOX	P50XN	FMVLP50XN	A
LOOX	P50XN	FMVLP50XNV	A
LOOX	P70WN	FMVLP70WN	A
LOOX	P70WN	FMVLP70WNV	A
LOOX	P70XN	FMVLP70XN	A
LOOX	P70XN	FMVLP70XNV	A
LOOX	P70YN	FMVLP70YN	A
LOOX	P70YN	FMVLP70YNV	A
LOOX	S73A	FMVLS73A	A

ノートパソコン			対応 コネクタ
シリーズ名	モデル名	型番	
LOOX	S73AW	FMVLS73AW	A
LOOX	S80B	FMVLS80B	A
LOOX	S80B/W	FMVLS80BW	A
LOOX	S80C	FMVLS80C	A
LOOX	S80C/W	FMVLS80CW	A
LOOX	S9/70	FMVLS970	A
LOOX	S9/70	FMVLS970S	A
LOOX	S9/70W	FMVLS970W	A
LIFEBOOK	FMV-B8240	FMVNB5W3	A
LIFEBOOK	FMV-B8240	FMVNB5W4	A
LIFEBOOK	FMV-B8240	FMVNB5W8	A
LIFEBOOK	FMV-B8240	FMVNB5Y3	A
LIFEBOOK	FMV-B8240	FMVNB5Y4	A
LIFEBOOK	FMV-B8240	FMVNB5Y8	A
LIFEBOOK	FMV-B8240	FMVNB5YT3	A
LIFEBOOK	FMV-B8240	FMVNB5YT4	A
LIFEBOOK	FMV-B8240	FMVNB5YT8	A
LIFEBOOK	FMV-B8250	FMVNB6F3	A
LIFEBOOK	FMV-B8250	FMVNB6F4	A
LIFEBOOK	FMV-B8250	FMVNB6F8	A
LIFEBOOK	FMV-B8250	FMVNB6FC	A
LIFEBOOK	FMV-B8250	FMVNB6FT3	A
LIFEBOOK	FMV-B8250	FMVNB6FT4	A
LIFEBOOK	FMV-B8250	FMVNB6FT8	A
LIFEBOOK	FMV-B8250	FMVNB6FTC	A
LIFEBOOK	FMV-B8250	FMVNB6H3	A
LIFEBOOK	FMV-B8250	FMVNB6H4	A
LIFEBOOK	FMV-B8250	FMVNB6H8	A
LIFEBOOK	FMV-B8250	FMVNB6HC	A
LIFEBOOK	FMV-B8260	FMVNB7C4	A
LIFEBOOK	FMV-B8260	FMVNB7CC	A
LIFEBOOK	FMV-B8260	FMVNB7F4	A
LIFEBOOK	FMV-B8260	FMVNB7FC	A
LIFEBOOK	FMV-B8260	FMVNB7FT4	A
LIFEBOOK	FMV-B8260	FMVNB7FTC	A
LIFEBOOK	650MC8/W1	FMV8MCH***	A
LIFEBOOK	650MC8/W2	FMV8MCH***	A
LIFEBOOK	FMV-640MC5C/W	FMV5MCDTL5	A
LIFEBOOK	FMV-640MC5C/W	FMV5MCDTL6	A
LIFEBOOK	FMV-640MC5C/W	FMV5MCDTM5	A
LIFEBOOK	FMV-640MC5C/W	FMV5MCDTM6	A
LIFEBOOK	FMV-640MC5C/W	FMV5MCDWL5	A
LIFEBOOK	FMV-640MC5C/W	FMV5MCDWL6	A
LIFEBOOK	FMV-640MC5C/W	FMV5MCDWM5	A
LIFEBOOK	FMV-640MC5C/W	FMV5MCDWM6	A
LIFEBOOK	FMV-U8240	FMVNU5G13	A
LIFEBOOK	FMV-U8240	FMVNU5G23	A
LIFEBOOK	FMV-U8240	FMVNU5G24	A
LIFEBOOK	FMV-U8250	FMVNU6G13	A
LIFEBOOK	FMV-U8250	FMVNU6G1C	A
LIFEBOOK	FMV-U8250	FMVNU6G23	A
LIFEBOOK	FMV-U8250	FMVNU6G24	A
LIFEBOOK	FMV-U8270	FMVNU8E1C	A
LIFEBOOK	FMV-U8270	FMVNU8E14	A

■SONY

ノートパソコン			対応 コネクタ
シリーズ名	モデル名	型番	
VAIO TypeT	VGN-T30B/L		A
VAIO TypeT	VGN-T30B/T		A
VAIO TypeT	VGN-T51B/L		A
VAIO TypeT	VGN-T52B/L		A
VAIO TypeT	VGN-T70B/L		A
VAIO TypeT	VGN-T71B/L		A
VAIO TypeT	VGN-T71B/T		A
VAIO TypeT	VGN-T72B/L		A
VAIO TypeT	VGN-T72B/T		A
VAIO TypeT	VGN-T90PS		A
VAIO TypeT	VGN-T90S		A
VAIO TypeT	VGN-T91PS		A
VAIO TypeT	VGN-T91S		A
VAIO TypeT	VGN-T92PSY1		A
VAIO TypeT	VGN-T92PSY2		A
VAIO TypeT	VGN-T92PSY3		A
VAIO TypeT	VGN-TX50B/B		A
VAIO TypeT	VGN-TX51B/B		A
VAIO TypeT	VGN-TX52B/B		A
VAIO TypeT	VGN-TX72B/B		A
VAIO TypeT	VGN-TX73B/B		A
VAIO TypeT	VGN-TX90PS		A
VAIO TypeT	VGN-TX90PS1		A
VAIO TypeT	VGN-TX90PS3A		A
VAIO TypeT	VGN-TX90S		A
VAIO TypeT	VGN-TX91PS		A
VAIO TypeT	VGN-TX91S		A
VAIO TypeT	VGN-TX92PS		A
VAIO TypeT	VGN-TX92PS1		A
VAIO TypeT	VGN-TX92PS2		A
VAIO TypeT	VGN-TX92S		A
VAIO TypeT	VGN-TX93HS		A
VAIO TypeT	VGN-TX93NS		A
VAIO TypeT	VGN-TX93S		A
VAIO TypeU	VGN-U50		A
VAIO TypeU	VGN-U70P		A
VAIO TypeU	VGN-UX50		A
VAIO TypeU	VGN-UX70		A
VAIO TypeU	VGN-UX71		A
VAIO TypeU	VGN-UX72		A
VAIO TypeU	VGN-UX90PS		A
VAIO TypeU	VGN-UX90S		A
VAIO TypeU	VGN-UX91NS		A
VAIO TypeU	VGN-UX91NS ゼロスピンダル		A
VAIO TypeU	VGN-UX91S		A
VAIO TypeU	VGN-UX91S ゼロスピンダル		A
VAIO TypeU	VGN-UX92NS		A
VAIO TypeU	VGN-UX92NS ゼロスピンダル		A
VAIO TypeU	VGN-UX92S		A
VAIO TypeU	VGN-UX92S ゼロスピンダル		A
	ZSN-VGNTX51BB		A
	ZSN-VGNTX52BB		A
	ZSN-VGNTX72BB		A
	ZSN-VGNTX92PS1		A
	ZSN-VGNTX92PS2		A
	ZSN-VGINUX50		A
	ZSN-VGINUX71		A
	ZSN-VGINUX72		A

ノートパソコン			対応 コネクタ
シリーズ名	モデル名	型番	
TOUGHBOOK	CF-18	CF-18AC1AXS	C
TOUGHBOOK	CF-18	CF-18AW1A2S	C
TOUGHBOOK	CF-18	CF-18AW1AXS	C
TOUGHBOOK	CF-18	CF-18DW1AXS	C
TOUGHBOOK	CF-18	CF-18EC1AXS	C
TOUGHBOOK	CF-18	CF-18FW1AXS	C
TOUGHBOOK	CF-18	CF-18GC1AXS	C
TOUGHBOOK	CF-18	CF-18KW1AXS	C
TOUGHBOOK	CF-18	CF-18LC1AXS	C
TOUGHBOOK	CF-18	ZPA-CF18KW1AXS	C
TOUGHBOOK	CF-18	ZPA-CF18LC1AXS	C
Let's note	CF-A3	CF-A3全モデル	A
Let's note	CF-R1	CF-R1MCAXR	C
Let's note	CF-R1	CF-R1MD***	C
Let's note	CF-R1	CF-R1MFA2S	C
Let's note	CF-R1	CF-R1MFAXS	C
Let's note	CF-R1	CF-R1MTA2S	C
Let's note	CF-R1	CF-R1MV***	C
Let's note	CF-R1	CF-R1MXA2S	C
Let's note	CF-R1	CF-R1MXAXS	C
Let's note	CF-R1	CF-R1NCAXR	C
Let's note	CF-R1	CF-R1P全モデル	C
Let's note	CF-R1	CF-R1R全モデル	C
Let's note	CF-R2	CF-R2AC1A2S	C
Let's note	CF-R2	CF-R2AC1AXS	C
Let's note	CF-R2	CF-R2AC2AXP	C
Let's note	CF-R2	CF-R2AW1A2S	C
Let's note	CF-R2	CF-R2AW1AXP	C
Let's note	CF-R2	CF-R2AW1AXR	C
Let's note	CF-R2	CF-R2AW1AXS	C
Let's note	CF-R2	CF-R2AW1HXP	C
Let's note	CF-R2	CF-R2AW1QXP	C
Let's note	CF-R2	CF-R2AW3AXP	C
Let's note	CF-R2	CF-R2BC1A2S	C
Let's note	CF-R2	CF-R2BC1AXS	C
Let's note	CF-R2	CF-R2BC2AXP	C
Let's note	CF-R2	CF-R2BW1A2S	C
Let's note	CF-R2	CF-R2BW1AXP	C
Let's note	CF-R2	CF-R2BW1AXR	C
Let's note	CF-R2	CF-R2BW1AXS	C
Let's note	CF-R2	CF-R2BW1HXP	C
Let's note	CF-R2	CF-R2BW3AXP	C
Let's note	CF-R2	CF-R2CW1AXP	C
Let's note	CF-R2	CF-R2CW1AXR	C
Let's note	CF-R2	CF-R2CW1AXS	C
Let's note	CF-R2	CF-R2CW1HXP	C
Let's note	CF-R2	CF-R2CW3AXP	C
Let's note	CF-R3	CF-R3DC1AXS	C
Let's note	CF-R3	CF-R3DW1AXR	C
Let's note	CF-R3	CF-R3DW1AXS	C
Let's note	CF-R3	CF-R3EC1AXS	C
Let's note	CF-R3	CF-R3EW1AXR	C
Let's note	CF-R3	CF-R3EW1AXS	C
Let's note	CF-R3	CF-R3EW1AXS	C
Let's note	CF-R3	CF-R3FC1AXS	C
Let's note	CF-R3	CF-R3FC5AXS	C
Let's note	CF-R3	CF-R3FW1AXP	C
Let's note	CF-R3	CF-R3FW1AXR	C
Let's note	CF-R3	CF-R3FW1AXS	C
Let's note	CF-R3	CF-R3FWKAXP	C
Let's note	CF-R4	CF-R4GC5AXS	C

ノートパソコン			対応 コネクタ
シリーズ名	モデル名	型番	
Let's note	CF-R4	CF-R4GW5AXP	C
Let's note	CF-R4	CF-R4GW5AXR	C
Let's note	CF-R4	CF-R4GW5AXS	C
Let's note	CF-R4	CF-R4GWKAXP	C
Let's note	CF-R4	CF-R4HC4AXS	C
Let's note	CF-R4	CF-R4HW4AXP	C
Let's note	CF-R4	CF-R4HW4AXR	C
Let's note	CF-R4	CF-R4HW4AXS	C
Let's note	CF-R4	CF-R4HW4HXP	C
Let's note	CF-R4	CF-R4HWMAXP	C
Let's note	CF-R4	CF-R4HWMHXP	C
Let's note	CF-R4	CF-R4JC4AXS	C
Let's note	CF-R4	CF-R4JW4AXP	C
Let's note	CF-R4	CF-R4JW4AXR	C
Let's note	CF-R4	CF-R4JW4AXS	C
Let's note	CF-R4	CF-R4JWMAXP	C
Let's note	CF-R4	CF-R4JWNAXP	C
Let's note	CF-R5	CF-R5KC4AXS	C
Let's note	CF-R5	CF-R5KW4AXP	C
Let's note	CF-R5	CF-R5KW4AXR	C
Let's note	CF-R5	CF-R5KW4AXS	C
Let's note	CF-R5	CF-R5KWPAXP	C
Let's note	CF-R5	CF-R5LC4AXS	C
Let's note	CF-R5	CF-R5LW4AXP	C
Let's note	CF-R5	CF-R5LW4AXR	C
Let's note	CF-R5	CF-R5LW4AXS	C
Let's note	CF-R5	CF-R5LWVAXP	C
Let's note	CF-T1	CF-T1PCA2S	C
Let's note	CF-T1	CF-T1PCAXP	C
Let's note	CF-T1	CF-T1PCAXR	C
Let's note	CF-T1	CF-T1PCAXS	C
Let's note	CF-T1	CF-T1PCHXP	C
Let's note	CF-T1	CF-T1PCQXP	C
Let's note	CF-T1	CF-T1PDAXP	C
Let's note	CF-T1	CF-T1PDAXR	C
Let's note	CF-T1	CF-T1PDAXS	C
Let's note	CF-T1	CF-T1PTA2S	C
Let's note	CF-T1	CF-T1PWA2S	C
Let's note	CF-T1	CF-T1PWAXP	C
Let's note	CF-T1	CF-T1PWAXR	C
Let's note	CF-T1	CF-T1PWAXS	C
Let's note	CF-T1	CF-T1PWHPXP	C
Let's note	CF-T1	CF-T1PWQXP	C
Let's note	CF-T1	CF-T1RCA2S	C
Let's note	CF-T1	CF-T1RCAXR	C
Let's note	CF-T1	CF-T1RCAXS	C
Let's note	CF-T1	CF-T1RDAXR	C
Let's note	CF-T1	CF-T1RDAXS	C
Let's note	CF-T1	CF-T1RWA2S	C
Let's note	CF-T1	CF-T1RWAXR	C
Let's note	CF-T1	CF-T1RWAXS	C
Let's note	CF-T2	CF-T2AC1A2S	C
Let's note	CF-T2	CF-T2AC1AXS	C
Let's note	CF-T2	CF-T2AC2AXP	C
Let's note	CF-T2	CF-T2AC2AXR	C
Let's note	CF-T2	CF-T2AC2AXS	C
Let's note	CF-T2	CF-T2AW1A2S	C
Let's note	CF-T2	CF-T2AW1AXP	C
Let's note	CF-T2	CF-T2AW1AXR	C

ノートパソコン			対応 コネクタ
シリーズ名	モデル名	型番	
Let's note	CF-T2	CF-T2AW1AXS	C
Let's note	CF-T2	CF-T2AW1HXP	C
Let's note	CF-T2	CF-T2AW1QXP	C
Let's note	CF-T2	CF-T2AW3AXP	C
Let's note	CF-T2	CF-T2BC1A2S	C
Let's note	CF-T2	CF-T2BC1AXS	C
Let's note	CF-T2	CF-T2BC2AXP	C
Let's note	CF-T2	CF-T2BC2AXS	C
Let's note	CF-T2	CF-T2BT1AXS	C
Let's note	CF-T2	CF-T2BW1A2S	C
Let's note	CF-T2	CF-T2BW1AXP	C
Let's note	CF-T2	CF-T2BW1AXS	C
Let's note	CF-T2	CF-T2BW1HXP	C
Let's note	CF-T2	CF-T2BW3AXP	C
Let's note	CF-T2	CF-T2CW1AXP	C
Let's note	CF-T2	CF-T2CW1AXR	C
Let's note	CF-T2	CF-T2CW1AXS	C
Let's note	CF-T2	CF-T2CW1HXP	C
Let's note	CF-T2	CF-T2CW3AXP	C
Let's note	CF-T2	CF-T2DC1AXS	C
Let's note	CF-T2	CF-T2DW1AXR	C
Let's note	CF-T2	CF-T2DW1AXS	C
Let's note	CF-T2	CF-T2EC1AXS	C
Let's note	CF-T2	CF-T2EW1AXR	C
Let's note	CF-T2	CF-T2EW1AXS	C
Let's note	CF-T2	CF-T2FC1AXS	C
Let's note	CF-T2	CF-T2FW1AXP	C
Let's note	CF-T2	CF-T2FW1AXR	C
Let's note	CF-T2	CF-T2FW1AXS	C
Let's note	CF-T2	CF-T2FWJAXP	C
Let's note	CF-T4	CF-T4GC5AXS	C
Let's note	CF-T4	CF-T4GC6AXS	C
Let's note	CF-T4	CF-T4GW5AXP	C
Let's note	CF-T4	CF-T4GW5AXR	C
Let's note	CF-T4	CF-T4GW5AXS	C
Let's note	CF-T4	CF-T4GW6AXS	C
Let's note	CF-T4	CF-T4GWKAX	C
Let's note	CF-T4	CF-T4GWKAXP	C
Let's note	CF-T4	CF-T4HC4AXS	C
Let's note	CF-T4	CF-T4HC9AXS	C
Let's note	CF-T4	CF-T4HW4AXP	C
Let's note	CF-T4	CF-T4HW4AXR	C
Let's note	CF-T4	CF-T4HW4AXS	C
Let's note	CF-T4	CF-T4HW4HXP	C
Let's note	CF-T4	CF-T4HW9AXS	C
Let's note	CF-T4	CF-T4HWMAXP	C
Let's note	CF-T4	CF-T4HWMHXP	C
Let's note	CF-T4	CF-T4JWSAXP	C
Let's note	CF-T4	CF-T4JWSAXR	C
Let's note	CF-T4	CF-T4JUWAXP	C
Let's note	CF-T5	CF-T5KC4AXS	C
Let's note	CF-T5	CF-T5KC9AXS	C
Let's note	CF-T5	CF-T5KW4AXP	C
Let's note	CF-T5	CF-T5KW4AXR	C
Let's note	CF-T5	CF-T5KW4AXS	C
Let's note	CF-T5	CF-T5KW9AXS	C
Let's note	CF-T5	CF-T5KWMAXP	C
Let's note	CF-T5	CF-T5LC4AXS	C
Let's note	CF-T5	CF-T5LC9AXS	C
Let's note	CF-T5	CF-T5LW4AXP	C
Let's note	CF-T5	CF-T5LW4AXR	C

ノートパソコン			対応 コネクタ
シリーズ名	モデル名	型番	
Let's note	CF-T5	CF-T5LW4AXS	C
Let's note	CF-T5	CF-T5LW9AXS	C
Let's note	CF-T5	CF-T5LWVAXP	C
Let's note	CF-T5	CF-T5MC4AJS	C
Let's note	CF-T5	CF-T5MC4AXS	C
Let's note	CF-T5	CF-T5MC9AJS	C
Let's note	CF-T5	CF-T5MC9AXS	C
Let's note	CF-T5	CF-T5MW4AJP	C
Let's note	CF-T5	CF-T5MW4AJR	C
Let's note	CF-T5	CF-T5MW4AJS	C
Let's note	CF-T5	CF-T5MW4AXS	C
Let's note	CF-T5	CF-T5MW9AJS	C
Let's note	CF-T5	CF-T5MW9AXS	C
Let's note	CF-T5	CF-T5MWAJJP	C
Let's note	CF-T5	CF-T5MWVAJP	C
Let's note	CF-W2	CF-W2AC1A2S	C
Let's note	CF-W2	CF-W2AC1AXS	C
Let's note	CF-W2	CF-W2AW1A2S	C
Let's note	CF-W2	CF-W2AW1AXP	C
Let's note	CF-W2	CF-W2AW1AXR	C
Let's note	CF-W2	CF-W2AW1AXS	C
Let's note	CF-W2	CF-W2AW1HXP	C
Let's note	CF-W2	CF-W2AW1QXP	C
Let's note	CF-W2	CF-W2AW3AXP	C
Let's note	CF-W2	CF-W2BC1A2S	C
Let's note	CF-W2	CF-W2BC1AXS	C
Let's note	CF-W2	CF-W2BW1A2S	C
Let's note	CF-W2	CF-W2BW1AXP	C
Let's note	CF-W2	CF-W2BW1AXR	C
Let's note	CF-W2	CF-W2BW1AXS	C
Let's note	CF-W2	CF-W2BW1HXP	C
Let's note	CF-W2	CF-W2BW3AXP	C
Let's note	CF-W2	CF-W2CW1AXP	C
Let's note	CF-W2	CF-W2CW1AXR	C
Let's note	CF-W2	CF-W2CW1AXS	C
Let's note	CF-W2	CF-W2CW1HXP	C
Let's note	CF-W2	CF-W2CW3AXP	C
Let's note	CF-W2	CF-W2DC1AXS	C
Let's note	CF-W2	CF-W2DW1AXR	C
Let's note	CF-W2	CF-W2DW1AXS	C
Let's note	CF-W2	CF-W2DW6AXR	C
Let's note	CF-W2	CF-W2DW6AXS	C
Let's note	CF-W2	CF-W2DW6BXR	C
Let's note	CF-W2	CF-W2EC1AXS	C
Let's note	CF-W2	CF-W2EW1AXR	C
Let's note	CF-W2	CF-W2EW1AXS	C
Let's note	CF-W2	CF-W2EW6AXR	C
Let's note	CF-W2	CF-W2EW6AXS	C
Let's note	CF-W2	CF-W2FC1AXS	C
Let's note	CF-W2	CF-W2FW1AXP	C
Let's note	CF-W2	CF-W2FW1AXS	C
Let's note	CF-W2	CF-W2FW6AXP	C
Let's note	CF-W2	CF-W2FW6AXR	C
Let's note	CF-W2	CF-W2FW6AXS	C
Let's note	CF-W2	CF-W2FWKAXP	C
Let's note	CF-W2	CF-W2FWPAXP	C
Let's note	CF-W4	CF-W4GC5AXS	C
Let's note	CF-W4	CF-W4GW5AXS	C
Let's note	CF-W4	CF-W4GW9AXP	C
Let's note	CF-W4	CF-W4GW9AXR	C



ノートパソコン			対応 コネクタ
シリーズ名	モデル名	型番	
Let's note	CF-W4	CF-W4GW9AXS	C
Let's note	CF-W4	CF-W4GW9HXR	C
Let's note	CF-W4	CF-W4GWPAXP	C
Let's note	CF-W4	CF-W4HC4AXS	C
Let's note	CF-W4	CF-W4HW4AXS	C
Let's note	CF-W4	CF-W4HW8AXP	C
Let's note	CF-W4	CF-W4HW8AXR	C
Let's note	CF-W4	CF-W4HW8AXS	C
Let's note	CF-W4	CF-W4HW8HXP	C
Let's note	CF-W4	CF-W4HW8HXR	C
Let's note	CF-W4	CF-W4HWSAXP	C
Let's note	CF-W4	CF-W4HWSHXP	C
Let's note	CF-W4	CF-W4JW8AXP	C
Let's note	CF-W4	CF-W4JW8AXR	C
Let's note	CF-W4	CF-W4JW8AXS	C
Let's note	CF-W4	CF-W4JW8HXR	C
Let's note	CF-W4	CF-W4JWUAXP	C
Let's note	CF-W4	CF-W4WWFDXS	C
Let's note	CF-W5	CF-W5CWAJS	C
Let's note	CF-W5	CF-W5CWAJS	C
Let's note	CF-W5	CF-W5KC4AXS	C
Let's note	CF-W5	CF-W5KW4AXS	C
Let's note	CF-W5	CF-W5KW8AXP	C
Let's note	CF-W5	CF-W5KW8AXR	C
Let's note	CF-W5	CF-W5KW8AXS	C
Let's note	CF-W5	CF-W5KW8HXR	C
Let's note	CF-W5	CF-W5KWUAXP	C
Let's note	CF-W5	CF-W5LC4AXS	C
Let's note	CF-W5	CF-W5LW4AXS	C
Let's note	CF-W5	CF-W5LW8AXP	C
Let's note	CF-W5	CF-W5LW8AXR	C
Let's note	CF-W5	CF-W5LW8AXS	C
Let's note	CF-W5	CF-W5LW8HXR	C
Let's note	CF-W5	CF-W5LWVAXP	C
Let's note	CF-W5	CF-W5LWYAXP	C
Let's note	CF-W5	CF-W5MC4AJS	C
Let's note	CF-W5	CF-W5MC4AXS	C
Let's note	CF-W5	CF-W5MW4AJS	C
Let's note	CF-W5	CF-W5MW4AXS	C
Let's note	CF-W5	CF-W5MW8AJP	C
Let's note	CF-W5	CF-W5MW8AJR	C
Let's note	CF-W5	CF-W5MW8AJS	C
Let's note	CF-W5	CF-W5MW8AJSXP	C
Let's note	CF-W5	CF-W5MW8AXR	C
Let's note	CF-W5	CF-W5MW8AXS	C
Let's note	CF-W5	CF-W5MW8HJR	C
Let's note	CF-W5	CF-W5MW8HXR	C
Let's note	CF-W5	CF-W5MWAAJP	C
Let's note	CF-W5	CF-W5MWVAJP	C
Let's note	CF-W5	CF-W5NWFDXS	C
Let's note	CF-W5	CF-W5QW1AXS	C
Let's note	CF-W5	CF-W5QW1AXSSP	C
Let's note	CF-W5	CF-W5QW1HXS	C
Let's note	CF-W5	CF-W5QW1HXSSP	C
Let's note	CF-Y2	CF-Y2CC2AXS	C
Let's note	CF-Y2	CF-Y2CW2AXP	C
Let's note	CF-Y2	CF-Y2CW2AXS	C
Let's note	CF-Y2	CF-Y2CW4AXP	C
Let's note	CF-Y2	CF-Y2CW4AXR	C
Let's note	CF-Y2	CF-Y2CW4AXS	C
Let's note	CF-Y2	CF-Y2CW4HXP	C

ノートパソコン			対応 コネクタ
シリーズ名	モデル名	型番	
Let's note	CF-Y2	CF-Y2CW5AXP	C
Let's note	CF-Y2	CF-Y2DW1AXR	C
Let's note	CF-Y2	CF-Y2DW1AXS	C
Let's note	CF-Y2	CF-Y2EC2AXS	C
Let's note	CF-Y2	CF-Y2EW1AXR	C
Let's note	CF-Y2	CF-Y2EW1AXS	C
Let's note	CF-Y2	CF-Y2EW2AXS	C
Let's note	CF-Y2	CF-Y2EW6AXR	C
Let's note	CF-Y2	CF-Y2EW6AXS	C
Let's note	CF-Y2	CF-Y2FW3AXS	C
Let's note	CF-Y2	CF-Y2FW7AXP	C
Let's note	CF-Y2F	CF-Y2FW7AXR	C
Let's note	CF-Y2	CF-Y2FW7AXS	C
Let's note	CF-Y2F	CF-Y2FW7HXR	C
Let's note	CF-Y2	CF-Y2FWKAXP	C
Let's note	CF-Y2	CF-Y2FWPAXP	C
Let's note	CF-Y4	CF-Y4GC2AXS	C
Let's note	CF-Y4	CF-Y4GW2AXS	C
Let's note	CF-Y4	CF-Y4GW4AXS	C
Let's note	CF-Y4	CF-Y4GW8AXP	C
Let's note	CF-Y4	CF-Y4GW8AXR	C
Let's note	CF-Y4	CF-Y4GW8AXS	C
Let's note	CF-Y4	CF-Y4GWMAXP	C
Let's note	CF-Y4	CF-Y4GWSAXP	C
Let's note	CF-Y4	CF-Y4HC2AXS	C
Let's note	CF-Y4	CF-Y4HW2AXS	C
Let's note	CF-Y4	CF-Y4HW4AXS	C
Let's note	CF-Y4	CF-Y4HW8AXP	C
Let's note	CF-Y4	CF-Y4HW8AXR	C
Let's note	CF-Y4	CF-Y4HW8AXS	C
Let's note	CF-Y4	CF-Y4HW8HXP	C
Let's note	CF-Y4	CF-Y4HWSAXP	C
Let's note	CF-Y4	CF-Y4HWSHXP	C
Let's note	CF-Y4	CF-Y4JW8AXP	C
Let's note	CF-Y4	CF-Y4JW8AXR	C
Let's note	CF-Y4	CF-Y4JW8AXS	C
Let's note	CF-Y4	CF-Y4JWSAXP	C
TOUGHBOOK	CF-PIP	CF-PIP全モデル	C